

Instructions for Removing your iSkin nano Vibes (for iPod nano 4G)

Removing the iSkin nano Vibes from your beloved iPod nano 4G is a quick and easy 4-STEP process.

STEP 1:

Gently squeeze your iSkin nano Vibes + iPod nano 4G from both sides. This will loosen the iSkin nano Vibes, and detach it from the iPod nano 4G's surface.



STEP 2:

Place your thumbnail on the top edge of the iSkin nano Vibes (*note: your thumbnail should not be touching the iPod nano 4G*) and push from the bottom to nudge the nano out of the iSkin.



STEP 3: Flip the iSkin nano Vibes + iPod nano 4G over. Repeat STEP 2.



STEP 4:

Repeat STEP 2 and STEP 3 in a cycle, gently "nudging" the iPod nano 4G out of the iSkin Vibes. Do this until the iPod nano 4G is completely removed.

