

Maintenance

The ProTouch keyboard protector is designed to capture finger oils and particles that fall onto the keyboard. It is recommended that you remove and wash the protector thoroughly with warm water and a mild dishwashing detergent to remove grime that built up. Doing so may also help to prevent the spread of germs. **▲ Dry thoroughly before reapplying to the keyboard.**



Send us your feedback

We'd love to hear from you. Customer comments and suggestions are important elements in the development of future iSkin products.

Send your feedback to: feedback@iSkin.com

For FAQs regarding this product, visit us online at iSkin.com



The iSkin word mark and logo are registered trademarks of iSkin Inc., registered in Canada, the United States and other countries. All Rights Reserved 2007. iPod is a trademark or registered trademark of Apple Inc. MICROBAN is a registered trademark of Microban Products Company.

1 Year Limited Warranty

iSkin Inc. warrants to the original purchaser that the product will be free from defects in materials and/or workmanship for the period of 1 Year. The warranty period commences on the date of purchase from the authorized reseller/retailer. Your original purchase invoice, showing the date of purchase of the product from the reseller/retailer is your proof of the date of purchase. This proof of purchase is mandatory for any warranty issues. iSkin Inc. at its option will repair or replace, at no charge, any part that iSkin Inc. determines to be defective.

This warranty shall not apply if the product has been damaged by abuse, misuse, negligence, accident, modification, tampering or by any other causes unrelated to defective materials and/or workmanship including acts of God. iSkin's warranty only covers product(s) made by iSkin and does not cover third party product(s) sold by other companies. iSkin acknowledges that with normal use of products made by iSkin, the purchased product(s) will provide satisfactory performance as specified by product performance literature.

Repair or replacement as provided under this warranty is iSkin's exclusive right. ANY APPLICABLE IMPLIED WARRANTIES, INCLUDING WARRANTIES OR MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY LIMITED TO 365 DAYS FROM THE DATE OF PURCHASE AND ARE SUBJECT TO CONDITIONS SET FORTH IN THIS LIMITED WARRANTY. IN NO EVENT SHALL iSkin Inc. BE RESPONSIBLE FOR INCIDENTAL DAMAGES RESULTING FROM THE BREACH OF ANY EXPRESS OR IMPLIED WARRANTIES. This warranty gives you specific legal rights, and you may also have other legal rights, which vary from state to state, province to province, valid in the United States and Canada. Any shipping or other cost such as customs incurred costs, etc. from outside North America is the customers' responsibility.

Exclusions and Limitations

This Limited Warranty applies only to hardware product manufactured by iSkin Inc. that can be identified by the "iSkin" trademark, trade name, or logo affixed to it. This Limited Warranty does not apply to any non-iSkin products. This will include third party products packaged or sold with iSkin, any third party manufacturer may supply their own product warranty.

All inquiries with regards to the product warranty may be directed to: www.iSkin.com/warranty

iSkin

ProTouch

User's Guide




A The ProTouch Advantage

Using premium silicone with built-in antimicrobial protection to inhibit the growth of odor and stain causing bacteria, the iSkin ProTouch keyboard protector creates a barrier to keep dust, dirt and food spills, from ever touching the surface of your keyboard. It also helps to prevent key wear further extending the life of your keyboard.


Unlike plastic based keyboard protectors, the iSkin ProTouch is made from a premium silicone that's long-lasting and can be washed and reused as often as necessary. It also dampens loud keystrokes making it ideal for home, office and educational use.

1 Prepare your Apple Keyboard



Before using the iSkin ProTouch keyboard protector, unplug and wipe the keyboard thoroughly with a soft, lint-free cloth to remove any surface oil and dirt that may have built up. Doing so will also ensure a better fit for the iSkin.

2 Overlaying the ProTouch protector




1 Place the ProTouch keyboard protector over the keyboard starting from one end. Make sure the keys are matching.




2 Massage and align the iSkin over all keys ensuring that each key is properly covered.

Overlaying the ProTouch protector contd...



3 Lift the outside rim of the ProTouch over the edges of the keyboard starting at one end and continue all the way around until fitted.

4 If necessary, turn the keyboard upside down to ensure that the iSkin has been correctly fitted around the edges of the keyboard.



? About Microban® antimicrobial protection

Research studies have shown that the average keyboard can contain substantial amounts of bacteria. The iSkin ProTouch keyboard protector features a premium silicone material with a built-in antimicrobial product protection to inhibit the growth of odor and stain causing bacteria on the product - making it the first ever keyboard protector to offer this level of protection.



www.microban.com

Notice to user:

iSkin Inc. shall not be responsible for any damage, including consequential damage caused by defective goods, personal injuries, property damage or consequential economic loss. iSkin does not guarantee suitability of its product for your application. Furthermore, iSkin Inc., shall not be responsible for any damage, loss of data, service, or otherwise caused to the computer or keyboard when used with this product.